UNIVERSAL PEN ADAPTER

CRAVERLAND

HOW TO REMOVE THE ORIGINAL PEN HOLDER

STEP 1:Locate the original pen holder.



STEP 2:Open the clamp,squeeze the edge of pen holder bottom, push it till it pop out.



2nd SQUEEZE & PUSH

BOTTOM VIEW

Use your fingers to squeeze the edge a little and push upward.

HOW TO INSTALL THE ADAPTER & CALIBRATION UNIT TO MAKE PENS WORK

STEP 1:Place the calibration unit under Clamp A as below, use before every pen gets replaced for depth calibration.



STEP 2:Open the clamp,make the pen go through the adapter till it stands vertically on the calibration unit.



NOTE:For the pens that have soft tips, lift the pen a little with your fingers to let them just reach the calibration unit without over-pressed.

LIFT UP THE SOFT TIP PENS



NORMAL OVER-PRESSED

HOW TO INSTALL THE ADAPTER AND MAKE PENS WORK

STEP 3: Adjust the adapter to the front not to get too close or touch the back component of the machine.



TOP VIEW

STEP 4:Close the clamp and screw on the thumbscrew until it is not easy to pull out the pens nor too tight.Pay attention to ones with very light plastic pen bodies (such as the BIC crystal), and do not crush the pen bodies. Remove calibration unit after all is done.



NOTE

The pens brand names and logos are the registered trademarks of their respective owners. Any use of the pens brand names or model designation listed below for this product is made solely for purposes of demonstrating compatibility.

All the pens that have been tested are compatible with CRAVERLAND universal pen adapter, but not limited to these pens. For the models not listed,do a test run before any designs. All the pens with consumable tips like pencils and crayons are not applicable with this pen adapter, unless it is a very short-term run for a small design.

COMPATIBILITY OF PENS THAT HAVE BEEN TESTED WITH

Amazon Basics High Lighter
Amazon Basics Fine Point
Arteza Feather

BIC Crystal
BIC Round Stic
BIC Brite Liner Highlighter
BIC Intensity Fineliner
BIC Intensity Medium
BIC Intensity Fine Point
BIC Intensity Ultra Fine
BIC Marking Fine Point
BIC Marking Ultra Fine
BIC Mark-it Fine Point
BIC Mark-it Ultra Fine
BIC Soft Feel

Crayola Detail Gel
Crayola Fine Liner
Crayola Take Note
Crayola Super Tips

Cricut Fine Point
Cricut Stylus
Criut Joy Metallic Marker

Papermate Inkjoy Gel
Papermate Inkjoy Retractable
Papermate Flair Felt Tip UR
Papermate Flair Felt Tip M
Papermate Inkjoy Ball(1.0)

Pentel RSVP RT
Pentel RSVP BK91

Pilot V5 / V7
Pilot Fine Liner
Pilot Frixon Fineline
Pilot G2

Sakura Micron
Sakura Gelly Roll

Sharpie Paint
Sharpie Fine Point
Sharpie Art Pen
Sharpie Liquid
Sharpie Ultra Fine Point

COMPATIBILITY OF PENS THAT HAVE BEEN TESTED WITH

Crayola Detail Gel
Crayola Fine Liner
Crayola Take Note
Crayola Super Tips

Cricut Fine Point
Cricut Stylus
Criut Joy Metallic Marker

Papermate Inkjoy Gel
Papermate Inkjoy Retractable
Papermate Flair Felt Tip UR
Papermate Flair Felt Tip M
Papermate Inkjoy Ball(1.0)

Pentel RSVP RT
Pentel RSVP BK91

Pilot V5 / V7
Pilot Fine Liner
Pilot Frixon Fineline
Pilot G2

Sakura Micron
Sakura Gelly Roll

Sharpie Paint
Sharpie Fine Point
Sharpie Art Pen
Sharpie Liquid
Sharpie Ultra Fine Point

Stabilo 88
Stabilo Trio 2in1
Stabilo Trio AtoZ
Stabilo Power Felt Tip

STAEDTLER Triplus Textsurfer
STAEDTLER Triplus Fineliner
STAEDTLER 326
STAEDTLER 432
STAEDTLER 325

Uniball 153

Tombow Twintone
Tombow Playcolor Dot
Tombow ABT
Tombow Fudenosuke Brush
WE R MEMORY Glue Qill